

## 取付け説明書 / ATTACHMENT INSTRUCTIONS

この度は、ベスタクス カスタムジョグ”手裏剣”をお買い求め戴きまして、誠にありがとうございます。  
取付け前に、この説明書をお読み下さいます様、お願いします。

Thank you for purchasing Vestax Custom JOG plate "SHURIKEN". Please read through the instructions before attaching the bracket to use this product safely.

### ■ご注意：

お手持ちのVCI-300が、以下シリアル番号(VCI-300本体のリア面に表示されている番号)の場合、バネの無いタイプになります。  
以下手順のバネは省いて、そのまま取付けてください。

### <<バネ無し対象シリアル番号>>

頭に"G"がつかない番号、及びG8B063851 以前の番号

[1] お手持ちのVestax "VCI-300"のプラッター部分を、図aの様にネジ6箇所を外して、アクリル円盤上部のJOGプレートを取外してください。

### ■ご注意：

JOGプレート取外しの際に、アクリル円盤とJOGプレートの間にあるバネを失くさないようにしてください。

(図bをご参照ください)

[2] アクリル円盤にバネが図bの様に装着されていることを確認の上、[1]と逆の手順で図cの様にカスタムジョグ「手裏剣」を、付属ネジ6本を使用してVCI-300に取付けてください。

### ■NOTE：

VCI-300 units with the following serial numbers do not include springs in the screw holes.

Skip instructions for springs if your unit may apply.

Serial: All serials without "G" before the number and numbers before G8B063851.

[1] Unscrew the 6 screws securing the platter of the VCI-300 and remove the JOG plate.(fig.a)

### ■NOTE：

Keep the springs set between the JOG plate and acrylic platter safely while changing the plates.(fig.b)

[2] Check that the springs are set to the acrylic platter as shown in fig.b, then place SHURIKEN on top of the JOG wheel and secure with the 6 screws.

