


Thank you for purchasing the Vestax Original Replacement Parts:

SL /DF type of knobs, designed for Vestax crossfaders, input faders and dial faders units.



Instructions for use

- ◆ Use with the device for which it is knob designated.
- ◆ Before you deploy lightly rub the axis of the potentiometer industrial vaseline or technical lubricant (e.g. WD40).
- ◆ When deployed the big strength do not use!

Maintenance



- ◆ Use a clean lint-free cloth from cotton, moistened in water.
- ◆ Protect from sharp objects.
- ◆ Do not use any chemicals (no alcohol, no gasoline, no solvent)
- ◆ Do not use abrasive cleaners.


Cleaning procedure



- ◆ Prepare a solution of soapy water with 50% concentration of soap.
- ◆ The oven degreasing agent can also be used special W5 MF Reiniger.
- ◆ Soak the knob in the solution (best 24h / at 30°C solution temperature).
- ◆ After removing from solution the hard & soft dirt is released.
- ◆ Then you just need to wipe the buttons with a cotton cloth.
- ◆ Finally rinse with clean running water and dry.

Note

All types of Vestax knobs are made for certain devices only. When replacing them, follow the manufacturer's instructions / service manual.



ALL KNOBS AND BUTTONS ARE DESIGNED FOR YOUR MAXIMUM COMFORT