

## Vestax USB2.0HUB VUH-204 User's Guide

### ■ BEFORE USING

Thank you for purchasing a Vestax MIDI controller.

Certain computers may have insufficient USB specifications to operate AUDIO USB MIDI Controllers. Please use the included USB HUB if you experience any operation errors.

NOTE: If your computer cannot identify the Vestax MIDI controller, please try changing the USB port. Some computers have different specifications for each USB port, which can possibly cause a connection error.

Computers with insufficient USB bus power may also cause connection errors with MIDI controllers. If you may experience such an error, please use the exclusive power adaptor (not included) available for your MIDI controller.

### ■ SAFETY PRECAUTIONS

- DO NOT use the product in damp or dusty environments. Including places where it is exposed to rain.
- DO NOT use the product nearby a water environment.
- DO NOT attempt to dismount, service or modificate the product by yourself.
- DO NOT apply strong impact to the product.
- DO NOT apply strong force to the connection areas of the product.
- USE a soft cloth to wipe and clean the product.
- DO NOT apply alcohol, benzene or thinner to the product.

### ■ SPECIFICATIONS

[MODEL] Vestax VUH-204

[USB INTERFACE] USB2.0

(USB1.1 operation when connected to a USB 1.1 interface)

[MAXIMUM DATA TRANSFER SPEED USB2.0 High Speed Mode] 480Mbps(max),  
\* USB1.1: 12Mbps(max)

[USB PORT] 4

[VOLTAGE] 5V

[POWER ADAPTOR SUPPLY CURRENT] 4 ports together within 2000mA

[INCLUDED ITEMS] USB cable


(Power adaptor not included - DC5V 2000mA center plus)

### ■ OS REQUIREMENTS

Windows 95/98/ME/2000/XP/7/Vista

Mac 8.6 or later

### ■ EACH NAME



### ■ RECOMMENDED CONNECTION EXAMPLE

